

**OTOL<sup>®</sup>**

**Easy Way, Easy Live.**

# **INSTALLATION MANUAL TAPWARE**

[http:// www.otolmall.com](http://www.otolmall.com) | BATHROOM | KITCHEN | 2016-2017 OTOL Group

## Congratulations on your new OTOL purchase!

We would like to take this opportunity to thank you for your business with OTOL. It is our sincere hope that you are completely satisfied with your OTOL experience. We welcome any questions or comments you may have, and look forward to assisting you in the future.

For more information about OTOL products, please visit our website at: [www.otol.com.cn](http://www.otol.com.cn).

*Sincerely,*

*OTOL Customer Service Department*

### **Prior to Installation**

- Make sure that the cold and hot water lines are turned off
- Wrap all threaded connections with Teflon tape. Always wrap in a clockwise direction
- Cover your drain to avoid losing parts
- Do not disassemble the main faucet body, as it has been installed & commissioned correctly & precisely before delivery from the factory
- To keep the faucet from jamming, flush the water pipe before installation
- Using condition: Working pressure at 0.01-3.5MPa ( including cold & hot water pressure) with applicable water temperature: 4°C-90°C



***NOTE: This mixer must be installed with isolating stop taps in accordance with local authority installation codes. All mixers must be installed by a licensed plumber, failure to do so may void warranty.***

***All tapware must be installed in accordance with AS/NZD 3500 series.***

## Basin Mixer Assembly Instructions (Example OT-211090)

It is recommended a licensed plumber carry out all tapware installation.

All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty.



(Remark: The mass thickness to the desk is 35mm, and the installation hole diameter is 35mm.)

### 1. REMOVE

Remove and leave the screw tube nut cover and rubber washer from the body, ensure the O-ring washer positioning correctly to the body.

### 2. MOUNTING

Fit the mixer to the basin/bench.

### 3. POSITION

(Under the basin/bench) Position the screw tube nut and rubber washer onto the screw tube. Lock the mixer onto the sink by tightening the screw tube nut cover onto the screw tube nut.

### 4. CONNECTING

Position the rubber washer onto the water hoses screw nut. Connect the flexible water hoses to the copper tails and tighten. Connect the flexible water hoses to the main water supply lines, make sure the hot water is connected to the hot water hose.



### 5. INLINE FILTERS

The installation of stop taps and inline filters are recommended to ensure a cleaner flow of water to the mixer.

## Kitchen Mixer Assembly Instructions (Example OT-212047)

It is recommended a licensed plumber carry out all tapware installation.

All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty.



(Remark: The mass thickness to the desk is 35mm, and the installation hole diameter is 35mm.)

### 1. REMOVE

Remove and leave the screw tube nut cover and rubber washer from the body, ensure the O-ring washer positioning correctly to the body.

### 2. MOUNTING

Fit the mixer to the basin/bench.

### 3. POSITION

(Under the basin/bench)  
Position the screw tube nut and rubber washer onto the screw tube. Lock the mixer onto the sink by tightening the screw tube nut cover onto the screw tube nut.

### 4. CONNECTING

Position the rubber washer onto the water hoses screw nut. Connect the flexible water hoses to the copper tails and tighten. Connect the flexible water hoses to the main water supply lines, make sure the hot water is connected to the hot water hose.


### 5. INLINE FILTERS

The installation of stop taps and inline filters are recommended to ensure a cleaner flow of water to the mixer.

## Wall Basin Mixer Assembly Instructions (Example OT-211068)

It is recommended a licensed plumber carry out all tapware installation.

All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty.



### 1. CONNECTING

Fix the body on the wall and connect the hot and cold hoses.

Repair the wall and take care of the surface protection of the mixer.

### 2. POSITION

Install the cover plate on the body.

### 3. POSITION

Install the handle on the cartridge and fix it up with screw.


### 4. POSITION

Install the spout on the outlet and fix it up with screw.

## Shower Mixer Assembly Instructions (Example OT-216075/216076)


It is recommended a licensed plumber carry out all tapware installation.

All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty.



### 1. MOUNTING

Mount the mixer body into the wall, connect the body with the inlet and outlet pipes.



### 2. POSITION


Install the face plate onto the protective cylinder.

### 3. POSITION

Put the fixing washer on the face plate, install the diverter onto the mixer body and tighten with a spanner.

## Spray Kitchen Mixer Assembly Instructions (Example OT-212190)

It is recommended a licensed plumber carry out all tapware installation.  
All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty.




### 1. MOUNTING

Fit the mixer body onto the kitchen hole.

### 2. POSITION

Place the horseshoe washer on top of the horseshoe plate and fit it onto the mounting bolt using the mounting nut to tighten up the mixer from the underneath of the kitchen



### 3. POSITION


Install the flexible hoses and ensure the flexible hoses are hand tightened into place. (DO NOT USE SPANNER TO TIGHTEN AS IT CAN DAMAGE THE O RING)

The flexible hoses are to be fitted into the correct inlets for hot water and cold water. (Red band for hot and blue band for cold.)

## Spray Kitchen Mixer Assembly Instructions (Example OT-214139)

It is recommended a licensed plumber carry out all tapware installation.

All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty.



### 1.CONNECTING

Mount the body into the wall, connect the body with the inlet and outlet pipes.

### 2. POSITION

Install the face plate onto the protective cylinder.

### 3.CONNECTING

Connect the shower hoses, one side connects the body, and the other side connects the hand shower.


### 4.POSITION

Install the shower head.

## Bath Spout Assembly Instructions (Example OT-217051)

It is recommended a licensed plumber carry out all tapware installation.

All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty




### POSITION

Install the spout into the wall with rotation.

## Washing Machine Stops and Angel Valve Assembly Instructions (Example OT-217035+OT-411001)

It is recommended a licensed plumber carry out all tapware installation.

All installations should comply with the relevant requirements of AS/NZS 3500. Failure to do so will void warranty



### 1.POSITION

Install the decorative plate to the water pipe on the wall.

### 2.ROTATING

Rotate the body to the connection of the water pipe.

## Care & Maintenance

To keep the product clean & shining, follow the steps below:

1. Rinse with clean water & dry with a soft cloth
2. Do not clean with soaps, acid, polish, abrasives, or harsh cleaners
3. Do not use a cloth with a coarse surface
4. Unscrew the aerator and clean when necessary

\*This installation manual is subject to change without further notice.

## OTOL Brand Faucets Limited Lifetime Warranty

All products are guaranteed as follows:

1. 5 years guarantee against casting defaults and porosity;
2. 3 years guarantee against cartridge and valve defaults;
3. 12 months guarantee on washers and O rings;
4. 12 months guarantee on finish.

If a product fails due to defect in material or craftsmanship during the warranty period, OTOL will repair or replace the items at its sole discretion. Warranty does not apply when the item has been tampered with, misused, improperly installed, altered, or damaged due to abuse or accident. Proof of purchase (original sales receipt) must be provided to OTOL for all warranty claims. Please contact one of our representatives for any additional details.

All OTOL products must be installed by a licensed professional plumber or contractor to avoid any improper use or installation.

IN NO EVENT SHALL OTOL BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, INSTALLATION COST, LABOR, TRAVEL TIME, FREIGHT COSTS INCURRED, LOST PROFITS, OR CONTINGENT LIABILITIES.